

# Installation Guidelines

## Cabana Bench 6'-Surface Mount

**Tools Needed:** Ratchet set or wrenches.

### **Step 1: Posts and Beam**

Insert posts (Part #2) into surface mount legs (Part #14) and secure with bolts "A". Place beam (Part #3) on top of posts making sure bolt holes line up. Secure with bolts "A."

### **Step 2: Seat Plates**

Attach the (2) seat plates (Part #4) to the inside face of the posts (Part #2) with bolts "A".

### **Step 3: Durawood Bench Slats**

Attach (5) 3" x 4" Durawood bench slats (Part #6) to seat plate (Part #4) with bolt "B".

---

### **\*\*\*OPTIONAL BACK REST BENCH**

#### **Alternate Step 3: Durawood Bench Slats**

Sandwich the bent bench straps (Part #5) between seat plates (Part #4) and Durawood slats (Part #6) and secure with lag bolts "B".

---

### **Step 4: Gable Ends**

Attach gable ends (Part #7) to each end of beam (Part #3) with bolts "C".

### **Step 5: Perlins**

Attach (5) perlins (Part #8) to gable ends with bolts "D".

### **Step 8: Fabric Canopy**

1. Unfold canvas (Part #13) and drape it over the canopy frame. (The grommetted lacers are on the inside of the cover).
2. Pull the cover down over the corners making sure the canvas is square with the frame and wrinkles are pulled taut.
3. Starting at the center of the short sides (where the beam and gable meet) lace the rope through the grommets, working toward the other end. Pull the cover and rope tight as you work toward the other end. Tie off loose ends.

### **Step 7: Miscellaneous**

Use can of black spray paint (semi gloss, not included) to touch up scratches from shipping or erection.

Optional: Secure surface mount legs to concrete deck with bolts "E" (not included)