

Installation Guidelines

Cabana Bench Table 8-Surface Mount

Tools Needed: Ratchet set or wrenches

Step 1: Posts and Beam

Attach surface mount legs (Part #10) to 3"x3" posts (Part#2) with bolts "A". Place beam (Part #3) on top of posts (Part #2) making sure bolt holes line up and secure with bolts "A" and column plates (Part #9)

Step 2: Seat Plates

Attach the (2) seat plates (Part #4) to the inside face of the 3"x3" posts (Part #2) with bolts "A".

Step 3: Angle Iron, Bench Straps and Durawood Slats

1. Seat:

Sandwich the bench straps (Part #11) between seat plates (Part #4) and Durawood slats (Part #6) and secure with lag bolts "B" (*Note – Bolt "B" will travel through the angle iron (parts #12), seat plate (part#4), bench strap (part#11) and into the Durawood slat (part#6) in that sequence).

At center of Bench, sandwich the center bench strap (Part #15) between angle iron (Part #12) and Durawood slats (Part #6) and secure from the bottom with Bolt "B" *Note – Center strap will rest on top of angle iron.

2. Table:

Attach the (2) 3"x 3"x12" angle (Part #14) to the inside face of both 3"x3" posts with bolts "A". Place the 2"x2"x 6' Angle (Part #12) underneath the 3"x 3"x12" angle (Part #14) while placing (3) Durawood slats (Part #6) on top of angles (Part #14) and secure from the bottom-up with lag bolts "B". (*Note – Bolt "B" will travel through the 2"x2"x 6' Angle (Part #12), 3"x 3"x12" angle (Part #14) and Durawood slat (part#6) in that sequence).

Step 4: Gable Ends

Secure gable ends (Part #7) to each end of beam (Part #3) with bolts "C".

NOTE: 6"x6" plates to meet at beam end and center of gable end.

Step 5: Perlins

Attach (5) perlins (Part #8) to gable ends with bolts "D".

Step 6: Fabric Canopy

- 1. Unfold canvas (Part #13) and drape it over the canopy frame. (The grommetted lacers are on the inside of the cover).**
- 2. Pull the cover down over the corners making sure the canvas is square with the frame and wrinkles are pulled taut.**
- 3. Starting at the center of the short sides (where the beam and gable meet) lace the rope through the grommets, working toward the other end. Pull the cover and rope tight as you work toward the other end. Tie off loose ends.**

Step 7: Miscellaneous

Use can of black spray (semi gloss) paint to touch up scratches from shipping or erection.